

晶体管资料汇总

编号	名称	极性	功能	耐压	电流	功率	频率	配对管	封装
1	2N2222	NPN	通用	60V	0.8A	0.5W	25 / 200NS		21
2	2N2222A	NPN	高频放大	75V	0.6A	0.625W	300MHZ		21
3	2N2369	NPN	开关	40V	0.5A	0.3W	800MHZ		4A
4	2N2906	PNP	通用	40V	0.2A				21C
5	2N2907	NPN	通用	60V	0.6A	0.4W	26 / 70NS		4A
6	2N3055	NPN	功率放大	100V	15A	115W		MJ2955	12
7	2N3440	NPN	视放开关	450V	1A	1W	15MHZ	2N6609	6
8	2N3773	NPN	音频功放开关	160V	16A	50W			12
9	2N3904	NPN	通用	60V	0.2A				21E
10	2N5401	PNP	视频放大	160V	0.6A	0.625W	100MHZ	2N5551	21
11	2N5551	NPN	视频放大	160V	0.6A	0.625W	100MHZ	2N5401	21
12	2N5685	NPN	音频功放开关	60V	50A	300W			12
13	2N6050	PNP	音频功放开关	60V	12A	150W			12
14	2N6051	PNP	音频功放开关	80V	12A	150W			12
15	2N6277	NPN	功放开关	180V	50A	250W			12
16	2N6609	PNP	音频功放开关	160V	15A	150W	>2MHZ	2N3773	12
17	2N6678	NPN	音频功放开关	650V	15A	175W	15MHZ		12
18	2N6718	NPN	音频功放开关	100V	2A	2W			21 铁
19	3D15D	NPN	电源开关	300V	5A	50W			12
20	3DA87A	NPN	视频放大	100V	0.1A	1W			6
21	3DD102C	NPN	电源开关	300V	5A	50W			12
22	3DD15D	NPN	电源开关	300V	5A	50W			12
23	3DG6B	NPN	通用	20V	0.02A	0.1W	150MHZ		6
24	3DG6C	NPN	通用	25V	0.02A	0.1W	250MHZ		6
25	3DG6D	NPN	通用	30V	0.02A	0.1W	150MHZ		6
26	3DK2B	NPN	开关	30V	0.03A	0.2W			7
27	3DK4B	NPN	开关	40V	0.8A	0.8W			7
28	3DK7C	NPN	开关	25V	0.05A	0.3W	75MH		7
29	5609	NPN	音频低频放大	50V	0.8A	0.625W		5610	21
30	5610	PNP	音频低频放大	50V	0.8A	0.625W		5610	21
31	8050	NPN	高频放大	40V	1.5A	1W	100MHZ	8550	21
32	8550	PNP	高频放大	40V	1.5A	1W	100MHZ	8050	21
33	9012	PNP	低频放大	50V	0.5A	0.625W		9013	21
34	9012	PNP	低频放大	50V	0.5A	0.625W		9013	贴片
35	9013	NPN	低频放大	50V	0.5A	0.625W		9012	贴片
36	9013	NPN	低频放大	50V	0.5A	0.625W		9012	21
37	9014	NPN	低噪放大	50V	0.1A	0.4W	150HMZ	9015	21
38	9015	PNP	低噪放大	50V	0.1A	0.4W	150MHZ	9014	21
39	9018	NPN	高频放大	30V	0.05A	0.4W	1000MHZ		21
40	9626	NPN	通用						21
41	A1009	PNP	功放开关	350V	2A	15W			BCE
42	A1013	PNP	视频放大	160V	1A	0.9W		C2383	21
43	A1015	PNP	通用	60V	0.1A	0.4W	8MHZ	C1815	21
44	A1020	PNP	音频开关	50V	2A	0.9W			21

晶体管资料汇总

45	A1123	PNP	低噪放大	150V	0.05A	0.75W			21
46	A1162	PNP	通用贴片	50V	0.15A	0.15W			21D
47	A1175	PNP	通用	60V	0.10A	0.25W	180MHZ		
48	A1213	PNP	超高频	50V	0.15A		80MHZ		贴片
49	A1216	PNP	功放开关	180V	17A	200W	20MHZ	C2922	BCE
50	A1220P	PNP	音频功放开关	120V	1.5A	20W	150MHZ		29
51	A1265	PNP	功放开关	140V	10A	100W	30MHZ	C3182	BCE
52	A1295	PNP	功放开关	230V	17A	200W	30MHZ	C3264	BCE
53	A1301	PNP	功放开关	160V	12A	120W	30MHZ	C3280	BCE
54	A1302	PNP	功放开关	200V	15A	120W	30MHZ	C3281	BCE
55	A1358	PNP		120V	1A	10W	120MHZ		BCE
56	A1444	PNP	高速电源开关	100V	15A	30W	80MHZ		BCE
57	A1494	PNP	功放开关	200V	17A	200W	20MHZ	C3858	BCE
58	A1516	PNP	功放开关	180V	12A	130W	25MHZ		BCE
59	A1668	PNP	电源开关	200V	2A	25W	20MHZ		BCE
60	A1785	PNP	驱动	120V	1A	1W	140MHZ		BCE
61	A1941	PNP	音频功放形状	140V	10A	100W		C5198	BCE
62	A1943	PNP	功放开关	230V	15AA	150W		C5200	BCE
63	A1988	PNP	功放开关						BCE
64	A634	PNP	音频功放开关	40V	2A	10W			28E
65	A708	PNP	音频开关	80V	0.7A	0.8W			6
66	A715C	PNP	音频功放开关	35V	2.5A	10W	160MHZ		29
67	A719	PNP	通用	30V	0.50A	0.625W	200MHZ		ECB
68	A733	PNP	通用	50V	0.1A		180MHZ		21
69	A741	PNP	开关	20V	0.1A		70 / 120NS		4
70	A781	PNP	开关	20V	0.2A		80 / 160NS		39B
71	A928	PNP	通用	20V	1A	0.25W			ECB
72	A933	PNP	通用	50V	0.1A		140MHZ		21
73	A940	PNP	音频功放开关	150V	1.5A	25W	4MHZ	C2073	28
74	A950	PNP	通用	30V	0.8A	0.6W			21
75	A966	PNP	音频激励输出	30V	1.5A	0.9W	100MHZ	C2236	21
76	A968	PNP	音频功放开关	160V	1.5A	25W	100MHZ	C2238	28
77	B1020	PNP	功放开关	100V	7A	40W			28
78	B1079	PNP	达林顿功放	100V	20A	100W		D1559	30
79	B1114	PNP	通用贴片	20V	2A		180MHZ		ECB
80	B1185	PNP	功放开关	60V	3A	25W	70MHZ	D1762	28B
81	B12	PNP	音频	30V	0.05A	0.05W			G—
82	B1215	PNP	功放开关贴片	120V	3A	20W	130MHZ		BCE
83	B1240	PNP	功放开关	40V	2A	1W	100MHZ		39B
84	B1316	PNP	达林顿功放	100V	2A	10W			54B
85	B1317	PNP	音频功放	180V	15A	150W		D1975	BCE
86	B1375	PNP	音频功放	60V	3A	2W	9MHZ		BCE
87	B1400	PNP	达林顿功放	120V	6A	25W		D1590	28B
88	B1429	PNP	功放开关	180V	15A	150W			BCE
89	B1494	PNP	达林顿功放	120V	20A	120W		D2256	BCE

晶体管资料汇总

90	B205	PNP	音频功放开关	80V	20A	80W			锗管
91	B449 锗管	PNP	功放开关	50V	3.5A	22.5W			12
92	B631K	PNP	音频功放开关	120V	1A	8W	130MHZ	D600K	29
93	B647	PNP	通用	120V	1A	0.9W	140MHZ	D667	21
94	B649	PNP	视放	180V	1.5A	20W		D669	29
95	B669	PNP	达林顿功放	70V	4A	40W			28
96	B673	PNP	达林顿功放	100V	7A	40W			28
97	B675	PNP	达林顿功放	60V	7A	40W			28
98	B688	PNP	音频功放开关	120V	8A	80W		D718	BCE
99	B734	PNP	通用	60V	1A	1W		D774	39B
100	B744	PNP	音频功放开关	70V	3A	10W			29
101	B772	PNP	音频功放开关	40V	3A	10W		D882	29
102	B774	PNP	通用	30V	0.1A	0.25W			21
103	B817	PNP	音频功放形状	160V	12A	100W		D1047	30
104	B834	PNP	功放开关	60V	3A	30W			28
105	BC307	PNP	通用	50V	0.2A	0.3W			21a
106	BC327	PNP	低噪音频	50V	0.8A	0.625W		BC337	CBE
107	BC337	NPN	音频激励低噪	50V	0.8A	0.625W		BC327	21a
108	BC338	NPN	通用激励	50V	0.8A	0.6W			21a
109	BC546	NPN	通用	80V	0.2A	0.5W			21a
110	BC547	NPN	通用	50V	0.2A	0.5W	300MHZ		CBE
111	BD135	NPN	音频功放	45V	1.5A	12.5W			29
112	BD136	PNP	音频功放	45V	1.5A	12.5W		BD137	29
113	BD137	NPN	音频功放	60V	1.5A	12.5W		BD136	29
114	BD138	PNP	音频功放	60V	1.5A	12.5W		BD139	29
115	BD139	PNP	音频功放	80V	1.5A	12.5W		BD138	29
116	BD237	NPN	音频功放	100V	2A	25W		BD238	29
117	BD238	PNP	音频功放	100V	2A	25W		BD237	29
118	BD243	NPN	音频功放	45V	6A	65W		BD244	28
119	BD244	PNP	音频功放	45V	6A	65W		BD243	28
120	BD681	NPN	达林顿功放	100V	4A	40W		BD682	29
121	BD682	PNP	达林顿功放	100V	4A	40W		BD681	29
122	BF458	NPN	视放	250V	0.1A	10W			29
123	BU1508DX	NPN	开关功放	1500V	8A	35W			28
124	BU208A	NPN	彩行	1500V	5A	12.5W			12
125	BU208D	NPN	彩行	1500V	5A	12.5W			12
126	BU2506DX	NPN	开关功放	1500V	7A	50W	600NS		30
127	BU2508AF	NPN	开关功放	1500V	8A	125W	600NS		30
128	BU2508AX	NPN	开关功放	1500V	8A	125W	600NS		30
129	BU2508DF	NPN	开关功放	1500V	8A	125W	600NS		30
130	BU2508DX	NPN	开关功放	1500V	8A	50W	600NS		30
131	BU2520AF	NPN	开关功放	1500V	10A	150W	1/500NS		30
132	BU2520DF	NPN	开关功放	1500V	10A	150W	1/500NS		30
133	BU2520DX	NPN	开关功放	1500V	10A	50W	600NS		30
134	BU2522AF	NPN	开关功放	1500V	11A	150W	350NS		30

晶体管资料汇总

135	BU2525AF	NPN	开关功放	1500V	12A	150W	350NS	30
136	BU2525AX	NPN	开关功放	1500V	12A	150W	350NS	30
137	BU2527AF	NPN	开关功放	1500V	15A	150W		30
138	BU2532AW	NPN	开关功放	1500V	15A	150W		30
139	BU323	NPN	达林顿功放	450V	10A	125W		28
140	BU406	NPN	行管	400V	7A	60W		28
141	BU508A	NPN	行管	1500V	7.5A	75W		28
142	BU508A	NPN	行管	1500V	7.5A	75W		28
143	BU508D	NPN	行管	1500V	7.5A	75W		28
144	BU806	NPN	功放	400V	8A	60W		28
145	BU932R	NPN	功放	500V	15A	150W		12
146	BU941	NPN	功放开关	500V	15A	175W	达林顿	12
147	BUH515	NPN	行管	1500V	10A	80W		BCE
148	BUH515D	NPN	行管	1500V	10A	80W		BCE
149	BUS13A	NPN	开关功放	1000V	15A	175W		12
150	BUS14A	NPN	开关功放	1000V	30A	250W		12
151	BUT11A	NPN	开关功放	1000V	5A	100W		28
152	BUT12A	NPN	开关功放	450V	10A	125W		28
153	BUV26	NPN	音频功放开关	90V	14A	65W	250NS	28
154	BUV28A	NPN	音频功放开关	225V	10A	65W	250NS	28
155	BUV48A	NPN	音频功放开关	450V	15A	150W		30
156	BUW13A	NPN	功放开关	1000V	15A	150W		30
157	BUX48	NPN	功放开关	850V	15A	125W		12
158	BUX84	NPN	功放开关	800V	2A	40W		30
159	BUX98A	NPN	功放开关	400V	30A	210W	5MHZ	12
160	C1008	NPN	通用	80V	0.7A	0.8W	50MHZ	21
161	C1044	NPN	视放	45V	0.3A		2.2GHZ	6
162	C1162	NPN	音频功放	35V	1.5A	10W		21
163	C1213	NPN	监视器专用	30V	0.5A	0.4W		39B
164	C1216	NPN	高速开关	40V	0.2A		T,20 n S	6
165	C1222	NPN	低噪放大	60V	0.1A		100MHZ	21
166	C1317	NPN	通用	30V	0.5A	0.625W	200MHZ	21EBC
167	C1317	NPN	通用	30V	0.5A	0.625W	200MHZ	21ECB
168	C1344	NPN	通用低噪	30V	0.1		230MHZ	ECB
169	C1494	NPN	发射	36V	6A	PQ="40W"	175MHZ	40A
170	C1507	NPN	视放	300V	0.2A	15W		28
171	C1674	NPN	HF/ZF	30V	0.02A		600MHZ	21
172	C1733	NPN	孪生对管	30V	0.05A		2GHZ	6
173	C1733	NPN	孪生对管	30V	2GHZ			小铁
174	C1815	NPN	通用	60V	0.15A	0.4W	8MHZ	A1015 21
175	C1855	NPN	HF/ZF	20V	0.02A		550MHZ	21F
176	C1875	NPN	彩行	1500V	3.5A	50W		12
177	C1906	NPN	高频放大	30V	0.05A		1000MHZ	21
178	C1942	NPN	彩行	1500V	3A	50W		12
179	C1959	NPN	通用	30V	0.4A	0.5W	300MHZ	21

晶体管资料汇总

180	C1970	NPN	手机发射	40V	0.6A	PQ="1".3W	175MHZ	28
181	C1971	NPN	手机发射	35V	2A	PQ-7.0W	175MHZ	28A
182	C1972	NPN	手机发射	35V	3.5A	PQ="15W"	175MHZ	28A
183	C2012	NPN	高放	30V	0.03A		200MHZ	21
184	C2027	NPN	行管	1500V	5A	50W		12
185	C2036	NPN	高放低噪	80V	1A	1—4W		29
186	C2068	NPN	视频放大	300V	0.05A	1.5W	80MHZ	28E
187	C2073	NPN	功率放大	150V	1.5A	25W	4MHZ	A940
188	C2078	NPN	音频功放开关	80V	3A	10W	150MHZ	28
189	C2120	NPN	通用	30V	0.8A	0.6W		21
190	C2228	NPN	视频放大	160V	0.05A	0.75W		21
191	C2230	NPN	视频放大	200V	0.1A	0.8W		21
192	C2233	NPN	音频功放开关	200V	4A	40W		28
193	C2236	NPN	通用	30V	1.5A	0.9W		A966
194	C2238	NPN	音频功放开关	160V	1.5A	25W	100MHZ	A968
195	C2320	NPN	通用	50V	0.2A	0.3W	200MHZ	21
196	C2335	NPN	视频功放	500V	7A	40W		28
197	C2373	NPN	功放	200V	7.5A	40W		28
198	C2383	NPN	视频开关	160V	1A	0.9W		A1013
199	C2443	NPN	功放开关	600V	50A	400W		大铁
200	C2458	NPN	通用低噪	50V	0.15A	0.2W		21ECB
201	C2481	NPN	音频功放开关	150V	1.5A	20W		29
202	C2482	NPN	视频放大	300V	0.1A	0.9W		21
203	C2500	NPN	通用	30V	2A	0.9W	150MHZ	21
204	C2594	NPN	音频功放开关	40V	5A	10W		29
205	C2611	NPN	视频放大	300V	0.1A	1.25W		29
206	C2625	NPN	音频功放开关	450V	10A	80W		30
207	C2682	NPN	NF/Vid	180V	0.1A	8W		29
208	C2688	NPN	视放管	300V	0.2A	10W	80MHZ	29
209	C2690	NPN	音频功放开关	120V	1.2A	20W	150MHZ	A1220P
210	C2751	NPN	电源开关	500V	15A	120W		BCE
211	C2837	NPN	音频功放开关	150V	10A	100W		30
212	C2898	NPN	音频功放开关	500V	8A	50W		28
213	C2922	NPN	音频功放开关	180V	17A	200W	50MHZ	A1216
214	C294	NPN	柔生对管	25V	0.05A		200MHZ	6
215	C3026	NPN	开关管	1700V	5A	50W		12
216	C3030	NPN	开关管	900V	7A	80W.	达林顿	BCE
217	C3039	NPN	电源开关	500V	7A	50W		28
218	C3058	NPN	开关管	600V	30A	200W		12
219	C3148	NPN	电源开关	900V	3A	40W		28
220	C3150	NPN	电源开关	900V	3A	50W		28
221	C3153	NPN	电源开关	900V	6A	100W		30
222	C3182	NPN	功放开关	140V	10A	100W		A1265
223	C3198	NPN	高频放大	60V	0.15A	0.4W	130MHZ	21
224	C3262	NPN	功放	800V	10A	100W		BCE

晶体管资料汇总

225	C3264	NPN	P A 功放开关	230V	17A	200W	B=170	A1295	BCE
226	C3280	NPN	音频功放开关	160V	12A	120WB=100			30
227	C3280	NPN	功放开关	160V	12A	120W	30MHZ	A1301	BCE
228	C3281	NPN	音频功放开关	200V	15A	150W	30MHZ		30
229	C3281	NPN	功放开关	200V	15A	120W	30MHZ	A1302	BCE
230	C3300	NPN	音频功放开关	100V	15A	100W			30
231	C3310	NPN	电源开关	500V	5A	40W			28C
232	C3320	NPN	电源开关	500V	15A	80W			28C
233	C3355	NPN	高频放大	20V	0.1A		6500MHZ		21F
234	C3358	NPN	高频放大	20V	0.1A		7000MHZ		40B
235	C3457	NPN	电源开关	1100V	3A	50W			BCE
236	C3460	NPN	电源开关	1100V	6A	100W			BCE
237	C3466	NPN	电源开关	1200V	8A	120W			BCE
238	C3505	NPN	电源开关	900V	6A	80W			28B
239	C3527	NPN	电源开关	500V	15A	100W			BCE
240	C3528	NPN	电源开关	500V	20A	150W			BCE
241	C3595	NPN	射频	30V	0.5A	1.2W			29
242	C3679	NPN	电源开关	900V	5A	100W	6MHZ		BCE
243	C3680	NPN	电源开关	900V	7A	120W	6MHZ		BCE
244	C3688	NPN	彩行	1500V	10A	150W			BCE
245	C3720	NPN	彩行	1200V	10A	200W			12
246	C3783	NPN	高压高速开关	900V	5A	100W			BCE
247	C3795	NPN	高压高速开关	900V	5A	40W			BCE
248	C380	NPN	高频放大	35V	0.03A		250MHZ		21
249	C3807	NPN	低噪放大	30V	2A	1.2W	260MHZ		BCE
250	C3858	NPN	功放开关	200V	17A	200W	20MHZ	A1494	BCE
251	C3866	NPN	高压高速开关	900V	3A	40W			BCE
252	C3873	NPN	高压高速开关	500V	12A	75W	30MHZ		BCE
253	C3886	NPN	开关行管	1400V	8A	50W	8MHZ		BCE
254	C3893	NPN	行管	1400V	8A	50W	8MHZ		28B
255	C3907	NPN	功放开关	180V	12A	130W	30MHZ		28B
256	C3953	NPN	视放	120V	0.2A	1.3W	400MHZ		29
257	C3987	NPN	达林顿	50V	3A	20W			28
258	C3995	NPN	行管	1500V	12A	180W			BCE
259	C3997	NPN	行管	1500V	15A	250W			BCE
260	C3998	NPN	行管	1500V	25A	250W			BCE
261	C4024	NPN	功放开关	100V	10A	35W	24MHZ		BCE
262	C4038	NPN	门电路	50V	0.1A	0.3W	180MHZ		BCE
263	C4059	NPN	高速开关	600V	15V	130W	0.5/2.2US		BCE
264	C4106	NPN	电源开关	500V	7A	50W	20MHZ?		BCE
265	C4111	NPN	开关行管	1500V	10A	150W			BCE
266	C4119	NPN	微波炉开关	1500V	15A	250W			BCE
267	C4231	NPN	音频功放	800V	2A	30W			50C
268	C4237	NPN	高压高速开关	1000V	8A	120W	30MHZ		BCE
269	C4242	NPN	高压高速开关	450V	7A	40W			BCE

晶体管资料汇总

270	C4297	NPN	电源开关	500V	12A	75W	10MHZ		BCE
271	C4382	NPN	功放开关	200V	2A	25W	20MHZ	A1668	BCE
272	C4429	NPN	电源开关	1100V	8A	60W			BCE
273	C4517	NPN	音频功放	550V	3A	30W	6MHZ		BCE
274	C4532	NPN	大屏行管	1700V	10A	200W			BCE
275	C458	NPN	通用	30V	0.1A		230MHZ		21
276	C4581	NPN	电源开关	600V	10A	65W	20MHZ		BCE
277	C4582	NPN	电源开关	600V	15A	75W	20MHZ		BCE
278	C4584	NPN	电源开关	1200V	6A	65W	20MHZ		BCE
279	C4706	NPN	电源开关	900V	14A	130W	6MHZ		BCE
280	C4742	NPN	彩行	1500V	6A	50W			46
281	C4745	NPN	彩行	1500V	6A	50W			46
282	C4747	NPN	彩行	1500V	10A	50W			46
283	C4769	NPN	微机行管	1500V	7A	60W			BCE
284	C4897	NPN	行管	1500V	20A	150W			BCE
285	C4913	NPN	大屏视放管	2000V	0.02A	35W			BCE
286	C4924	NPN	音频功放	800V	10A	70W			BCE
287	C4927	NPN	SONY29 行管	1500V	8A	50W			BCE
288	C4927	NPN	行管	1500V	8A	50W			BCE
289	C4928	NPN	行管	1500V	15A	150W			BCE
290	C4941	NPN	行管	1500V	6A	65W	500/380NS		BCE
291	C4953	NPN	功放开关	500V	2A	25W	t="300nS"		BCE
292	C5020	NPN	彩行	1000V	7A	100W			BCE
293	C5068	NPN	彩行	1500V	10A	50W			BCE
294	C5086	NPN	彩行	1500V	10A	50W			BCE
295	C5088	NPN	彩行	1500V	10A	50W			BCE
296	C5129	NPN	彩显行管	1500V	8A	50W			BCE
297	C5132	NPN	彩行	1500V	16A	50W			BCE
298	C5142	NPN	彩行	1500V	20A	200W			BCE
299	C5144	NPN	大屏彩行	1700V	20A	200W			BCE
300	C5148	NPN	大屏彩行	1500V	8A	50W			BCE
301	C5149	NPN	高速高频行管	1500V	8A	50W			BCE
302	C5198	NPN	功放开关	140V	10A	100W			BCE
303	C5198	NPN	音频功放形状	140V	10A	100W		A1941	BCE
304	C5200	NPN	功放开关	230V	15A	150W		A1943	BCE
305	C5200	NPN	功放开关	230V	15A	150W		A1943	BCE
306	C5207	NPN	彩行	1500V	10A	50W			BCE
307	C5243	NPN	彩行	1700V	15A	200W			BCE
308	C5244	NPN	彩行	1700V	15A	200W			BCE
309	C5249	NPN	功放开关	600V	3A	35W	6MHZ		BCE
310	C5250	NPN	开关	1000V	7A	100W			BCE
311	C5251	NPN	彩行	1500V	12A	50W			BCE
312	C5252	NPN	彩行	1500V	15A	100W			BCE
313	C5294	NPN	彩行	1500V	20A		t =200MS		BCE
314	C5296	NPN	开关管带阻	1500V	8A	80W			BCE

晶体管资料汇总

315	C5297	NPN	开关管	1500V	16A	60W		BCE
316	C5331	NPN	大屏彩显行管	1500V	15A	180W		BCE
317	C536	NPN	通用	40V	0.1A		180MHZ	21
318	C5411	NPN	彩显行管 17"	1500V	14A	60W		BCE
319	C546	NPN	高放	30V	0.03A	0.15W	600MHZ	21ECB
320	C665	NPN	音频功放开关	125V	5A	50W	15MHZ	12
321	C680	NPN	音频功放开关	200V	2A	30W	20MHZ	11
322	C752	NPN	通用	30V	0.1A		300MHZ	21
323	C815	NPN	通用	60V	0.2A	0.25W		21
324	C828	NPN	通用	45V	0.05A	0.25W		21
325	C900	NPN	低噪放大	30V	0.03A		100MHZ	21
326	C945	NPN	通用	50V	0.1A	0.5W	250MHZ	21
327	D1025	NPN	达林顿功放	200V	8A	50W		28
328	D1037	NPN	音频功放开关	150V	30A	180W		BCE
329	D1047	NPN	音频功放开关	160V	12A	100W		B817 30
330	D1071	NPN	达林顿功放	300V	6A	40W		28
331	D110	NPN	音频功放开关	130V	10A	100W	1MHZ	12
332	D1163A	NPN	行偏转用	350V	7A	40W	60MHZ	28
333	D1175	NPN	行偏转用	1500V	5A	100W		12
334	D1273	NPN	音频功放	80V	3A	40W	50MHZ	28
335	D1302	NPN	音频	25V	0.5A	0.5W	200MHZ	21
336	D1397	NPN	开关	1500V	3.5A	50W	3MHZ	BCE
337	D1398	NPN	开关	1500V	5A	50W	3MHZ	BCE
338	D1403	NPN	彩行	1500V	6A	120W		BCE
339	D1403	NPN	彩行	1500V	6A	120W		BCE
340	D1415	NPN	功放电源开关	100V	7A	40W	达林顿	BCE
341	D1416	NPN	功放电源开关	80V	7A	40W	达林顿	BCE
342	D1427	NPN	彩行	1500V	5A	80W	带阻尼	BCE
343	D1428	NPN	彩行	1500V	6A	80W	带阻尼	28B
344	D1431	NPN	彩行	1500V	5A	80W		28B
345	D1433	NPN	彩行	1500V	7A	80W		28B
346	D1439	NPN	彩行	1500V	3A	80W		BCE
347	D1541	NPN	彩行	1500V	3A	80W		28B
348	D1545	NPN	彩行	1500V	5A	50W		28B
349	D1547	NPN	彩行	1500V	7A	80W		BCE
350	D1554	NPN	彩行	1500V	3.5A	80W		BCE
351	D1555	NPN	彩行	1500V	5A	80W		BCE
352	D1556	NPN	彩行	1500V	6A	80W		BCE
353	D1559	NPN	达林顿功放	100V	20A	100W		B1079 BCE
354	D1590	NPN	达林顿功放	150V	8A	25W		28
355	D1623	NPN	彩行	1500V	4A	70W		28B
356	D1640	NPN	达林顿功放	120V	2A	1.2W		29
357	D1651	NPN	彩行	1500V	5A	60W	3MHZ	SP
358	D1710	NPN	彩行	1500V	5A	50W		BCE
359	D1718	NPN	音频功放	180V	15A	150W	20MHZ	28C

晶体管资料汇总

360	D1724	NPN	开关	120V	3A		180MHZ		29
361	D1762	NPN	音频功放开关	60V	3A	25W	90MHZ	B1185	BCE
362	D1843	NPN	低噪放大	50V	1A	1W			BCE
363	D1849	NPN	彩行	1500V	7A	120W			50A
364	D1850	NPN	彩行	1500V	7A	120W			50A
365	D1859	NPN	音频	80V	0.7A	1W	120MHZ		50A
366	D1863	NPN	音频	120V	1A	1W	100MHZ		50A
367	D1877	NPN	彩行	1500V	4A	50W	带阻尼		30
368	D1879	NPN	彩行	1500V	6A	60W	带阻尼		30
369	D1887	NPN	彩行	1500V	10	70W			20
370	D1930	NPN	达林顿	100V	2A	1.2W	达林顿		21
371	D1959	NPN	彩行	1400V	10A	50W			BCE
372	D1975	NPN	音频功放	180V	15A	150W		B1317	53A
373	D1978	NPN	达林顿	120V	1.5A	0.9W			21
374	D1980	NPN	达林顿	100V	2A	10W			61B
375	D1981	NPN	达林顿	100V	2A	1W			EBC
376	D1993	NPN	音频低噪	55V	0.1A	0.4W			45B
377	D1994A	NPN	音频驱动	60V	1A	1W			EBC
378	D1997	NPN	激励管	40V	3A	1.5W	100MHZ		45B
379	D2008	NPN	音频功放	80V	1A	1.2W			EBC
380	D2012	NPN	音频功放	60V	3A	2W	3MHZ		BCE
381	D2136	NPN	功放	80V	1A	1.2W			EBC
382	D2155	NPN	音频功放	180V	15A	150W			53A
383	D2253	NPN	彩显行管	1700V	6A	50W			BCE
384	D2256	NPN	达林顿功放	120V	25A	125W		B1494	46
385	D2334	NPN	彩行	1500V	5A	80W			28B
386	D2335	NPN	彩行	1500V	7A	100W	带阻尼		BCE
387	D2349	NPN	大屏彩显行管	1500V	±10A	50W			BCE
388	D2374	NPN	功放开关	60V	3A	25W	30MHZ		BCE
389	D2375	NPN	高放大倍数	80V	3A	25W	50MHZ		BCE
390	D2388	NPN	达林顿	90V	3A	1.2W			EBC
391	D2445	NPN	彩行	1500V	12.5A	120W			BCE
392	D2498	NPN	彩行	1500V	6A	50W			BCE
393	D2588	NPN	点火器用						BCE
394	D325	NPN	功放开关	50V	3A	25W			BCE
395	D385	NPN	达林顿功放	100V	7A	30W			11
396	D400	NPN	通用	25V	1A	0.75W			21
397	D401	NPN	音频功放开关	200V	2A	20W			28
398	D40C	NPN							BCE
399	D415	NPN	音频功放开关	120V	0.8A	5W			29
400	D438	NPN	通用	500V	1A	0.75W	100MHZ		21
401	D560	NPN	达林顿功放	150V	5A	30W			BCE
402	D600K	NPN	音频功放开关	120V	1A	8W	130MHZ	B631K	29
403	D633	NPN	音频功放开关	100V	7A	40W	达林顿		28
404	D633拆	NPN	音频功放开关	100V	7A	40W	达林顿		28

晶体管资料汇总

405	D637	NPN	通用	60V	0.1A		150MHZ		39E
406	D667	NPN	视频放大	120V	1A	0.9W	140MHZ	B647	21
407	D667	NPN	通用	120V	1A	0.9W	140MHZ	B649	21
408	D669	NPN	视频放大	180V	1.5A	20W	140MHZ	B649	29
409	D718	NPN	音频功放开关	120V	8A	80W		B668	30
410	D774	NPN	通用	100V	1A	1W		B734	39B
411	D789	NPN	音频输出	100V	1A	0.9			21
412	D814	NPN	低噪放大贴片	150V	0.05A		150MHZ		BCE
413	D820	NPN	彩行	1500V	5A	50W			12
414	D870	NPN	彩行	1500V	5A	50W			12
415	D880	NPN	音频功放开关	60V	3A	10W			28
416	D882	NPN	音频功放开关	40V	3A	30W		B772	29
417	D884	NPN	音频功放开关	330V	7A	40W			28
418	D898	NPN	彩行	1500V	3A	50W			12
419	D951	NPN	彩行	1500V	3A	65W			12
420	D965	NPN	音频	40V	5A	0.75W			21
421	D966	NPN	音频	40V	5A	1W			21
422	D985	NPN	达林顿功放	150V	±1.5A	10W			29
423	D986	NPN	达林顿功放	150-80V	±1.5A	10W			29
424	D998	NPN	音频功放开关	120V	10A	80W	<1/3US		BCE
425	DK55	NPN	功放开关	400V	4A	65W			28
426	DK55	NPN	开关	400V	4A	60W			BCE
427	DTA114	PNP		160V	0.6A	0.625W			
428	DTC143	NPN	录像机用						
429	HPA100	NPN	大屏彩显行管	1500V	10A	150W			BCE
430	HPA150	NPN	大屏彩显行管	1500V	15A	150W			BCE
431	HQ1F3P	NPN	功放开关	20V	2A	2W			贴片
432	HSE830	PNP	音频功放	80V		115W	1MHZ	HSE800	BCE
433	HSE838	NPN	音频功放	80V		115W	1MHZ	HSE830	BCE
434	KSE800	NPN	达林顿	140V	4A	20W			28
435	MJ10012	NPN	达林顿	400V	10A	175W			12
436	MJ10015	NPN	电源开关	400V	50A	200W			12
437	MJ10016	NPN	电源开关	500V	50A	200W			12
438	MJ10025		电源开关	850V	20A	250W			12
439	MJ11015	PNP	铁达林顿	500V	10A				12
440	MJ11032	NPN	电源开关	120V	50A	300W		MJ11033	12
441	MJ11033	PNP	电源开关	120V	50A	300W		MJ11032	12
442	MJ13333	NPN	电源开关	400V	20A	175W			12
443	MJ14003	PNP	铁						12
444	MJ15024	NPN	音频功放开关	400V	16A	250W	4MHZ	MJ15025	12
445	MJ15025	PNP	音频功放开关	400V	16A	250W	4MHZ	MJ15024	12
446	MJ2955	PNP	音频功放开关	60V	15A	115W		MJ3055	12
447	MJ3055	NPN	音频功放开关	60V	15A	115W		MJ2955	12
448	MJ4502	PNP	音频功放开关	90V	30A	200W		MJ802	12
449	MJ802	NPN	音频功放开关	90V	30A	200W		MJ4502	12

晶体管资料汇总

450	MJE13003	NPN	功放开关	400V	1.5A	14W			29
451	MJE13005	NPN	功放开关	400V	4A	60W			28
452	MJE13007	NPN	功放开关	1500V	2.5A	60W			28
453	MJE271	PNP	达林顿	100V	2A	15W	6MHZ		29
454	MJE2955T	PNP	音频功放开关	60V	10A	75W	2MHZ	MJE3055T	BCE
455	MJE3055T	NPN	音频功放开关	70V	10A	75W	2MHZ	MJE2955T	BCE
456	MJE340	NPN	视放	300V	0.5A	20W		MJE350	29
457	MJE350	PNP	视放	300V	0.5A	20W		MJE340	29
458	MJE5822	PNP	音频功放开关	500V	8A	80W			BCE
459	MJE9730	NPN							BCE
460	MN650	NPN	行管	1500V	6A	80W			BCE
461	MPS2222A	NPN	高频放大	75V	0.6A	0.625W	300MHZ		21
462	MPSA42	NPN	电话视频放大	300V	0.5A	0.625W		MPSA92	21E
463	MPSA92	PNP	电话视频放大	300V	0.5A	0.625W		MPSA42	21E
464	ON4673	NPN							BCE
465	ON4873	NPN							BCE
466	T30G40	NPN	大功率开关管	400V	30A	300W			BCE
467	TIP102	NPN	音频功放开关	100V	8A	2W			28
468	TIP105	PNP	音频功放开关	60V	15A	80W	达林顿		28
469	TIP122	NPN	音频功放开关	100V	5A	65W		TIP127	28
470	TIP127	PNP	音频功放开关	100V	5A	65W		TIP122	28
471	TIP132	NPN	音频功放开关	100V	8A	70W		TIP137	28
472	TIP137	PNP	音频功放开关	100V	8A	70W		TIP132	28
473	TIP142	NPN	音频功放开关	100V	10A	125W		TIP147	30
474	TIP142 大	NPN	音频功放开关	100V	10A	125W		TIP147	30
475	TIP147	PNP	音频功放开关	100V	10A	125W		TIP142	30
476	TIP147 大	PNP	音频功放开关	100V	10A	125W		TIP142	30
477	TIP152		电梯用达林顿	400V	3A	65W			BCE
478	TIP31C	NPN	功放开关	100V	3A	40W	3MHZ	TIP32	BCE
479	TIP32C	PNP	功放开关	100V	3A	40W	3MHZ	TIP31	BCE
480	TIP35C	NPN	音频功放开关	100V	25A	125W	3MHZ	TIP36	30
481	TIP36C	PNP	音频功放开关	100V	25A	125W	3MHZ	TIP35	30
482	TIP41C	NPN	音频功放开关	100V	6A	65W	3MHZ	TIP42	30
483	TIP42C	PNP	音频功放开关	100V	6A	65W	3MHZ	TIP41	30