

PCM63元件清单			
电阻	数量	代用型号	数量
33欧1/4W	6		
75欧1/2W	1		
100欧1/2W	6	不接缓冲时只要2PCS	
240欧1/2W	9	270欧	9
1K 1/2W	5		
2K 1/2W	3		
4.7K1/2W	8		
330K1/4W	4	可不装	
<b>可调电阻 (立式)</b>			
2K	4		
5K	4	装LM317/337时装上	
100K	4	可不装	
<b>电感</b>			
47UH	10		
磁珠	1	可用跳线短接	
PE65612	1	DV709	1
<b>稳压管</b>			
12V	4		
15V	4		
LM1086-5	2		
LM317T	4		
LM337T	4		
LM317T/K	1	T是塑封, K是金封	
<b>三极管</b>			
MJE15030	4	NPN	
MJE15031	4	PNP	
注: LPF部分用MJE15030/15031时LM317/337不用			
对应的240欧和5K可调电阻也不用装			
<b>二极管</b>			
MR752	20		
<b>电容</b>			
0.1UF	51		
0.047UF	1		
0.01UF	3		
10UF/16V	6	最好用钽电容	
10UF/160V	4	RIFA无极电容	
2200PF	4		
47UF/50V	4		
100UF	31	其中18只可装立式或卧式	
2200UF/35V	10	可装立式或卧式	
6800UF/35V	4		
<b>芯片</b>			
CS8412IP	1		
DF1700P	1	SM5813APT	1

PCM63P	2	通过转接板上PCM1702/AD1862		
AD797	2	可自行选择合适自己的搭配		
NE5534	2			
BUF03	2	BUF634P	2	